


OVERAL DIMENSIONS - mm

The pump rotates in one direction only. This is indicated by an arrow on the pump housing. However, the pump has both of its shaft-ends led out and must be driven through one or the other depending on the direction of rotation of the power take-off.
 Because the pump rotates in one direction only, the positions of the suction and discharge ports cannot be reversed (see arrows on housing). The safety bypass cannot be reversed.



E	Bypass adjustment
J	Clearance for dismounting
P	Pump plate
V	Drain plug Pressure intake

18 KG

DATA

	SPEED RANGE	DELIVERY	PRESSION	REQUIRED POWER	The pumps CC8 10 can work at a pressure equal to 8 bar. They are normally delivered with a spring adjusted at 4 bar. When requested, they can be delivered with a spring adjusted at 8 bar.
	tr/mn	m3/h	bar	kW	
CC8 10 - A Viscosity < 40 cSt.	800 à 1000	10	8	2,8	
	600 à 1200	13	6	2,2	
	500 à 1500	17	4	2,5	

ASSEMBLY AND DISASSEMBLY OF PUMP


Make sure that the pump has been drained before starting disassembly.

TOOLS REQUIRED

Flat wrenches, 13
 Tube wrench, 17 mm.
 Circlip opening pliers.
 Screwdriver.

TO OPEN PUMP ON SIDE OPPOSITE TO DRIVE SYSTEM

Remove shaft-end cap 540 by pulling.
 Remove circlip 537.
 Unscrew the four screws 410.
 Unscrew the two screws 411 fitted with their nuts and place them in the two tapped holes T.
 Screw up the two screws at the same time so that the end-plate is gradually released along the centre line. When it is free on the shaft, hold it by hand and remove it.




TO OPEN PUMP ON DRIVE SIDE

Uncouple the pump by removing the U-joint or the coupling.
 Remove the key and then proceed in the same way as when dismantling on the other side.


TO REASSEMBLE

Lubricate the shaft slightly.
 Make sure that the end-plate seal is correctly positioned, check it and change it if necessary.
 Position the end-plate on the shaft and approach it as far as possible by hand.
 Finish fitting the end-plate, screwing the two nuts 412 gradually on to the two screws 411 (see drawing). Make sure that the end-plate is centered while screwing. When it is in place remove the screws and nuts. Turn one of the leak discharge holes downwards.
 Replace all parts (screws, circlips, cap).
 Screw up the longer screws 411 in the two bosses on the end-plate.



TO CHANGE THE VANES

Open the pump on one side or the other.
 Remove the vanes.
 Check for wear (see § on maintenance).
 If vane wear is abnormal, check surface condition of body and of end-plate faces.
 Refit the vanes (new if necessary) respecting the direction of assembly.
 Reassemble the pump.
 Turn it over by hand to check operation.




REPLACEMENT OF THE SHAFT SEAL

To disassemble

Remove the end-plate.
Release the integral rotary seal 697 attached to the shaft by inserting the tip of a screwdriver into one of the two notches.
Free the stationary 604 from the end-plate.
Check the condition of gaskets 403, 605 and 613, and the condition of the integral rotary seal 697.

To reassemble

With new parts, check the condition of contact surfaces between the stationary 604 and the integral rotary seal 697.
Replace the stationary o-ring 605, and then the stationary 604, in the end-plate.
Replace the integral rotary seal 697 on the shaft, taking care to engage the two tabs on the former into the notches machined in the rotor 301.
Replace all the other parts in reverse order to that of removal.




TO DISASSEMBLE AND REASSEMBLE THE BYPASS FOR INSPECTION

To disassemble

Set bypass at minimum pressure by unscrewing the nut.
* Note the number of turns when unscrewing so as to set the bypass at the same pressure on reassembly.
Unscrew the two bypass cap screws.
Remove spring.
Remove the poppet by pulling its cylindrical section with the fingers.
Check condition of bypass.
Clean all parts before reassembly.

To reassemble

Reassemble in reverse order of disassembly.
Set bypass at desired pressure by tightening nut the number of turns noted during disassembly.



MAINTENANCE

In addition to periodic lubrication of bearings (see general instructions), condition of the vanes must be checked every 700 hours :



Original height "h" = 20 mm
Change when "h" < 18 mm.


KEY : ▲ = parts and assemblies that can be supplied as spares.

Rep.	Nb.	DESIGNATION	Rep.	Nb.	DESIGNATION
▲ 098	1	SET OF SCREWS (410+411+412+723+856)	▲ 699	1	SET OF SHAFT SEAL O-RINGS
▲ 099	1	SET OF PUMP SEALS (126+403+807)	▲ 700	1	BALL BEARING COMPLETE
▲ 100		CASING COMPLETE	▲ 703	4	Ball bearing
101	1	Casing	705	2	Cover
115	1	Pump plate	708	2	Lubricator nipple
116	2	Pump rivet	723	6	Cover screw
▲ 124	1	DRAIN PLUGS AND GASKETS	733	2	Protection ring
125	2	Drain plug	734	2	Spacer
126	2	Gasket	▲ 820	1	COMPENSATED BYPASS COMPLETE
▲ 300	1	ROTOR COMPLETE	▲ 823	1	Compensated poppet
301	1	Rotor	▲ 827	1	Adaptor nut
▲ 317	6	Set of vanes	▲ 898	1	ADJUSTMENT PIN ASSEMBLY
▲ 400	1	END PLATE COMPLETE	807	1	Seal
401	2	End plate	825	1	Thrust piece
410	8	End plate screws	826	1	Adjustment pin
411	4	End plate disassembly screw	831	1	Adjustment nut split-pin (see 899)
412	4	Disassembly nut	834	1	Adjustment nut (see 899)
404	2		835	1	Lock nut (see 899)
403	2	End plate seal	837	1	Adjustment seal (see 899)
▲ 500		SHAFT COMPLETE	856	3	Cover screw (see 899)
501	1	Shaft	▲ 824	1	SPRING 4 or 6 or 2,5
▲ 599		SET OF KEYS COMPLETE	▲ 899	1	SET OF BYPASS SEALS ADJUSTMENT NUTS (807+831+834+835+837)
508	1	Shaft end key			ALTERNATIVES
536	1	Sliding rotor key			
537	2	Retainer ring			
540	1	Shaft protection			
▲ 600	1	SHAFT SEAL COMPLETE	▲ 700a	1	REDUCTION GEAR UNIT
▲ 610	2	Stationary complete	▲ 703	4	COMPLETE BEARING
604	2	Stationary	705	1	Cover ball bearing
605	2	Stationary O-ring	▲ 706	1	Reduction gear side-plate
▲ 697	1	BLOCDIR ROTARY SEAL	708	2	Lubricator nipple
612	2	Shaft seal cup	723	3	Cover screw
613	2	Rotating O-ring	724	3	Side plate screw
614	2	Thrust piece	733	2	Protection ring
615	2	Spring	734	2	Spacer
616	2	Retainer shaft seal	752	4	Reduction gear screw
			753	4	Lock washer
			710	1	

NOTE - When ordering replacement parts, please give details as follows :

- TYPE and SERIAL NUMBER of pump (engraved on pump data plate)
- the words TECHNICAL FORM N° 301
- REFERENCE NUMBERS and NAMES OF PARTS required. Please note that the only parts that can be supplied, either separate parts or complete units, are those marked with a triangle (▲).





SPEED REDUCER FLANGED ON PUMP