

A compressors

Minimize Line Losses

Lower pressure drops:
 Less power required
 Faster transfer

Use larger line sizes

Keep runs as short as possible

Eliminate unneeded fittings,
 Particularly on the liquid line

Use low restriction fittings and valves

Clean strainer elements

