

**PARTS LIST  
PUMP & TAPE  
AM NOYEE**

Keep this parts lists with Installation, Operation and Maintenance Instructions.

To order the required spare parts, indicate the desired Reference(s).

- ◆ Sets of parts or parts available to order.

**Mechanical seal :**


B I : Bronze/Stainless steel

Z.I. la Plaine des Isles - 2 rue des Caillottes F-89000 AUXERRE - France

Tel : +33 (0)3 86 49 86 30 • Fax : +33 (0)3 86 49 87 17


contact.mouvex@psgdover.com • www.mouvex.com

# AM NOYEE PUMP




# AM NOYEE PUMP


## Mechanical seal



## Bypass



# TAPE AM NOYEE



# AM NOYEE PUMP

\* 1, 2, 4... : Quantity in equipment - (1), (2), (4)... : Quantity in kit

Item	Available	Description	Qty*	Ref.	Maintenance kit	Wear part
98	◆	<b>FULL SET OF SCREWS</b>	1	AUX301787		
105		STUD	(4)			
106		SCREW	(6)			
106A		NUT	(6)			
115		NUT	(4)			
116		WASHER	(10)			
141		SCREW	(6)			
142		WASHER	(6)			
202		STUD	(12)			
206		NUT	(12)			
207		WASHER	(12)			
236		STUD	(24)			
237		NUT	(24)			
238		WASHER	(24)			
798	◆	<b>FULL SET OF SCREWS FOR BALL BEARING</b>	1	AUX303336		
706		SCREW	(6)			
721		WASHER	(6)			
99	◆	<b>SET OF PUMP SEALS</b>	1	AUX301788	■	
104		O-RING	(1)			
109		SEAL	(1)			
406		SEAL	(2)			
416		SEAL	(1)			
12403	◆	O-RING	1	AUX229425		●
100	◆	<b>MAIN BODY, COMPLETE</b>	1	AUX301779		
101		MAIN BODY	(1)			
105		STUD	(4)			
106		SCREW	(6)			
106A		NUT	(6)			
115		NUT	(4)			
116		WASHER	(10)			
817	◆	<b>SET OF BYPASS FIXING STUDS</b>	1	AUX301780		
813		NUT	(2)			
814		STUD	(2)			
815		WASHER	(12)			
891		WASHER	(2)			
138	◆	<b>MAIN BODY BEARING, COMPLETE</b>	1	AUX301781		
103	◆	BEARING BUSHING - BRONZE	1	AUX201710	■	●
108		PLUG	(1)			
109		SEAL	(1)			
141		SCREW	(6)			
142		WASHER	(6)			
414		FRONT COVER BEARING	(1)			
416		SEAL	(1)			
200	◆	<b>CYLINDER, COMPLETE</b>	1	AUX301782	■	●
201		CYLINDER	(1)			
202		STUD	(12)			
203		BULKHEAD	(1)			
206		NUT	(12)			
207		WASHER	(12)			
236		STUD	(24)			
237		NUT	(24)			
238		WASHER	(24)			
235	◆	<b>GASKET</b>	1	AUX218892		

# AM NOYEE PUMP

\* 1, 2, 4... : Quantity in equipment - (1), (2), (4)... : Quantity in kit

Item	Available	Description	Qty*	Ref.	Maintenance kit	Wear part
399	◆	<b>GUIDE BLOCK, COMPLETE</b>	1	AUX300772		
310		SPRING	(1)			
311		PUSHER	(1)			●
314		PIN	(2)			
400	◆	<b>COMPLETE FRONT COVER</b>	1	AUX301783		
402	◆	FRONT BUSHING SET	1	AUX301785		
404		GUIDE	(2)			●
405		STUD	(2)			
406		SEAL	(2)			
407		SEAL	(2)			
408		BLIND NUT	(2)			
12401		FRONT COVER	(1)			
500	◆	<b>SHAFT BLOCDIR COMPLETE</b>	1	AUX301797	■	
501	◆	SHAFT	1	AUX203635		
503	◆	PISTON BEARING	1	AUX316416		●
508	◆	KEY	1	AUX203858		
515	◆	COMPLETE SLEEVE	1	AUX300902		
521		SLEEVE	(1)			●
522		SCREW	(1)			
523		NUT	(1)			
524		PIN	(1)			
598	◆	BEARING SPRING COMPLETE	1	AUX301790		
504		SPRING	(4)			
511		SCREW	(4)			
600	◆	<b>MECHANICAL SEAL - BLOCDIR B I FKM</b>	1	AUX300835	■	
610		STATIONARY SEAL FACE COMPLETE	(1)			
604		STATIONARY SEAL FACE	(1)			
605		O-RING	(1)			
697		ROTATING PART	(1)			●
612		SEAL HOUSING	(1)			●
613		O-RING	(1)			
614		SPRING GUIDE	(1)			
615		SPRING	(1)			
616		CAGE	(1)			
698	◆	<b>FULL SET OF MOUNTING SCREWS</b>	1	AUX301794		
706		SCREW	(6)			
721		WASHER	(6)			
699	◆	<b>SET OF MECHANICAL SEAL SEALS - FKM</b>	1	AUX300826		
605		O-RING	(1)			
613		O-RING	(1)			
704		RING	(1)			
700	◆	<b>BALL BEARINGS COMPLETE</b>	1	AUX303337		
627	◆	PIN	1	AUX200143		
701		BEARING CAGE	(1)			
703	◆	BALL BEARING	1	AUX200557		●
705		COVER	(1)			
708		GREASE NIPPLE	(1)			
797	◆	BALL BEARING WASHERS AND GASKET SET	1	303341.00		
704		RING	(1)			
707		LIP SEAL	(1)			
717		SEAL	(1)			
731		WASHER	(1)			
733		METALLIC SEAL	(1)			
761		PIN	(1)			
798	◆	FULL SET OF SCREWS FOR BALL BEARING	1	AUX303336		
706		SCREW	(6)			
721		WASHER	(6)			

# AM NOYEE PUMP

\* 1, 2, 4... : Quantity in equipment - (1), (2), (4)... : Quantity in kit

Item	Available	Description	Qty*	Ref.	Maintenance kit	Wear part
<b>840</b>	◆	<b>BYPASS COMPLETE</b>	<b>1</b>	<b>AUX301795</b>		
824A		SPRING N°4	(1)			
869	◆	BYPASS CAP AND GASKET	1	AUX300741		
832		SEAL	(1)			
833		BYPASS CAP	(1)			
870	◆	BYPASS BODY	1	AUX301796		
812		PLUG	(1)			
841		BYPASS BODY	(1)			
848		SEAL	(1)			
856		STUD	(6)			
857		WASHER	(6)			
859		NUT	(6)			
878	◆	CENTERING SET	1	AUX300929		
876		CENTERING PIECE	(2)			
877		CENTERING GASKET	(2)			
897	◆	ADJUSTING SCREW_VALVE SET	1	AUX300858		
807		SEAL NUT	(1)			
825		SPRING GUIDE	(1)			
826		ADJUSTING SCREW	(1)			
828		NUT	(1)			
829		SPRING	(1)			
830		STOPPER	(1)			
831		PIN	(1)			
834		NUT	(1)			
837		O-RING	(1)			
864	◆	COMPLETE VALVE	1	AUX300937		
863		PIN	(1)			
864O		VALVE+STEM	(1)			
<b>899</b>	◆	<b>SET OF BYPASS SEALS</b>	<b>1</b>	<b>AUX312257</b>	■	
807		SEAL NUT	(1)			
829		SPRING	(1)			
831		PIN	(1)			
832		SEAL	(1)			
837		O-RING	(1)			
848		SEAL	(1)			
877		CENTERING GASKET	(2)			
<b>12300</b>	◆	<b>COMPLETE PISTON - BRONZE BUSHING</b>	<b>1</b>	<b>AUX316734</b>	■	
12301O		PISTON + BLOCK PIN	(1)			
12301		PISTON	(1)			●
12304	◆	SLIDE BLOCK SHAFT	1	AUX203916		●
12303 (1)	◆	PISTON BUSHING BRONZE (203631 FOR PUMPS BEFORE APRIL 2014)	1	AUX230193	■	●
12398O	◆	SLIDE BLOCK, COMPLETE	1	AUX316293		
12307	◆	SLIDE BLOCK + BUSHING	1	AUX316294		
12306		BUSHING	(1)			●
12312		SLIDE BLOCK	(1)			●
12308		WASHER	(1)			
12309		PISTON NUT	(1)			
<b>12403</b>	◆	<b>O-RING</b>	<b>1</b>	<b>AUX229425</b>		●

(1) AUX203631 for pumps before April 2014

## TAPE AM NOYEE

\* 1, 2, 4... : Quantity in equipment - (1), (2), (4)... : Quantity in kit

Item	Available	Description	Qty*	Ref.	Maintenance kit	Wear part
3699	◆	SPECIFICATION PLATE	1	AUX204092		
3700	◆	COMPLETE TAPE	1	AUX308083		
3701		TAPE	(1)			
3702		LIFTING EYE BOLTS	(2)			
		<b>TAPE AM NOYEE PARTS :</b>				
3901	◆	FLUSHING TUBING COMPLETE	1	AUX301811		
3623		CONNECTOR	(1)			
3629		BULKHEAD CONNECTOR	(1)			
3902		CONNECTOR	(1)			
3903	◆	VALVE	1	AUX204803		
3904		FUNNEL	(1)			
3905		ELBOW	(1)			
3906		SEAL	(1)			
3907		CONNECTOR	(2)			
3908		NIPPLE	(1)			
3909		NIPPLE	(1)			
3910		CONNECTOR	(1)			
3911		PLUG	(1)			
3912		CROSSPIECE	(2)			
3920	◆	DRAIN FRONT COVER	1	AUX301812		
3921		DRAIN	(1)			
3922		ELBOW	(1)			
3923		NIPPLE	(1)			
3924	◆	VALVE	1	AUX204803		
3925		SEAL	(1)			
3926		NIPPLE	(1)			
3927		COMPANION FLANGE STEEL	(2)			
3930	◆	GASKET	1	AUX203983		
3931		SCREW	(3)			
3932		NUT	(3)			
3933		WASHER	(3)			
3934		SEAL	(1)			
3935		SEAL	(1)			
3610	◆	COMPLETE VALVE	2	AUX301805		
3676		COMPLETE HOUSING & BALL	(1)			
3692		VALVE HOUSING	(1)			
3693		VALVE BALL	(1)			
3677		VALVE BRACKET	(1)			
3678		SCREW	(4)			
3679	◆	BALL MECHANICAL STOP	1	AUX201661		
3680	◆	SPRING	6	AUX201186		
3681		GASKET	(2)			
3682		FLANGE Ø 91	(1)			
3684		SCREW	(8)			
3685	◆	GASKET	1	AUX218896		
3686		STUD	(6)			
3687		PIN	(1)			
3688		WASHER	(4)			
3689		WASHER	(8)			
3690		WASHER	(6)			
3691		NUT	(6)			



# TAPE AM NOYEE

\* 1, 2, 4... : Quantity in equipment - (1), (2), (4)... : Quantity in kit

Item	Available	Description	Qty*	Ref.	Maintenance kit	Wear part
3617	◆	RIGHT VALVE PLATE	1	AUX204093		
3618	◆	LEFT VALVE PLATE	1	AUX204094		
3624	◆	GASKET	4	AUX218895		
3627	◆	BULKHEAD CONNECTOR	2	AUX214517		
3628	◆	SEAL	7	AUX218894		
3630	◆	CONNECTOR	1	AUX214519		
3632	◆	VALVE CONTROL ASSEMBLY	2	AUX301807		
3601	◆	VALVE GLAND PACKING	1	AUX230593		●
3633	◆	BEARING	1	AUX203617		
3634	◆	PACKING GLAND	1	AUX203618		
3635		SCREW	(4)			
3636	◆	SEAL	4	AUX200621		
3637		GASKET	(2)			
3638	◆	VALVE GLAND PACKING KIT FOR AM NOYEE	1	AUX310361		
3638A		VALVE GLAND PACKING	(3)			●
3639		SCREW	(2)			
3640		WASHER	(2)			
3641	◆	CONTROL VALVE SHAFT ASSEMBLY	1	AUX304153		
3642		VALVE SHAFT	(1)			
3643		SLEEVE	(1)			
3644	◆	SPRING ASSEMBLY	1	AUX304510		
3645		WASHER	(1)			
3646		SPRING	(1)			
3647	◆	INDICATOR COMPLETE	1	AUX301808		
3648		SCREW	(1)			
3649	◆	INDICATOR	1	AUX304444		
3650		INDICATOR HOUSING	(1)			
3651		ARROW	(1)			
3652	◆	VALVE CONTROL LEVER	1	AUX302574		
3656	◆	GREASING PIPE ASSEMBLY	2	AUX301810		
3631		CONNECTOR	(1)			
3657		SEAL	(2)			
3658		ADAPTOR	(1)			
3659		CONNECTOR	(1)			
3660		CONNECTOR	(1)			
3661	◆	GREASE NIPPLE	1	AUX201103		
3662		GREASING PIPE	(1)			
3664	◆	FULL SET OF SCREWS _ SEALS	1	AUX301806		
3665		SCREW	(8)			
3666	◆	GASKET	4	AUX218897		
3667		SCREW	(16)			
3668	◆	GASKET	2	AUX218896		
3669		STUD	(12)			
3670	◆	GASKET	4	AUX218893		
3671		NUT	(12)			
3672	◆	GASKET	4	AUX218895		
3673		WASHER	(36)			
3674	◆	EXTERNAL TUBING COMPLETE	2	AUX308717		
3675		FLANGE BORED Ø91	(1)			
3694	◆	GREASE PUMP AND HOSE KIT	1	AUX321629		
3611		HOSE	(1)			
3612		GREASE GUN CONNECTOR	(1)			
3663		GREASE PUMP	(1)			
3860	◆	COUPLING FLANGE	1	AUX209618		
3861	◆	COUPLING FLANGE	1	AUX209619		
3862	◆	ELASTIC TRANSITIONAL RING	1	AUX209604		●
3863	◆	COUPLING SLEEVE	1	AUX210253		